



Az Üzenetkezelő program SMS küldő modulja az alábbi mobilkészülékek használatát támogatja:

Alcatel

BenQ-Siemens

Falcom

LG

Motorola

Nokia

Sagem

Samsung

Sharp

Siemens

Sony Ericss.

Teltonika

Toshiba

ALCATEL

Alcatel One Touch 501
Alcatel One Touch 535
Alcatel One Touch 701
Alcatel One Touch 715
Alcatel One Touch 735

BENQ-SIEMENS

BenQ-Siemens AF51
BenQ-Siemens C31
BenQ-Siemens E71
BenQ-Siemens EF81
BenQ-Siemens M81
BenQ-Siemens S65v
BenQ-Siemens S68

FALCOM

Falcom SAMBA
Falcom Twist USB

LG

LG U8330

MOTOROLA

Motorola K1
Motorola L6
Motorola SLVR L7
Motorola V1075
Motorola V190
Motorola V195
Motorola V360
Motorola V3r
Motorola V3re
Motorola Z3

NOKIA

Nokia 2630
Nokia 3100
Nokia 3105
Nokia 3109c
Nokia 3110
Nokia 3120
Nokia 3200

Nokia 3210
Nokia 3220i
Nokia 3310
Nokia 3510i
Nokia 3650
Nokia 5110
Nokia 5140
Nokia 5140i
Nokia 5200
Nokia 5300
Nokia 6020
Nokia 6021
Nokia 6030
Nokia 6070
Nokia 6080
Nokia 6086
Nokia 6100
Nokia 6101
Nokia 6125
Nokia 6131
Nokia 6131
Nokia 6170
Nokia 6210
Nokia 6230
Nokia 6230i
Nokia 6234
Nokia 6267
Nokia 6270
Nokia 6280
Nokia 6288
Nokia 6300
Nokia 6310
Nokia 6310i
Nokia 6340i
Nokia 6600
Nokia 6610
Nokia 6610i
Nokia 6670
Nokia 6680
Nokia 6681
Nokia 6810
Nokia 7110
Nokia 7250i

Nokia 7360
Nokia 7500
Nokia 8310
Nokia 8800
Nokia 9210i
Nokia 9500
Nokia N30
Nokia N70
Nokia N73

SAGEM

Sagem my400X
Sagem my411x
Sagem my419X
Sagem my501X
Sagem myX-7
Sagem myX6-2

SAMSUNG

Samsung 129
Samsung SGH C 100
Samsung SGH-A701
Samsung SGH-L760
Samsung SGH-V710
Samsung SGH-Z107
Samsung SGH-Z150
Samsung SGH-Z300
Samsung SGH-Z400
Samsung SGH-Z510
Samsung Z370

SHARP

Sharp GX17

SIEMENS

Siemens A56
Siemens A60
Siemens A65
Siemens AX75
Siemens C35i
Siemens C45
Siemens C55
Siemens C60

Siemens C61
Siemens C65
Siemens C6V
Siemens CF62
Siemens CF75
Siemens CX65
Siemens CX75
Siemens EL71
Siemens ES75
Siemens M55
Siemens M65
Siemens MC35i
Siemens MC60
Siemens MC75
Siemens ME45
Siemens ME75
Siemens MT50
Siemens S45
Siemens S55
Siemens S65
Siemens S65
Siemens S75
Siemens SL45i
Siemens TC35

SONY ERICSSON

Sony Eric. A
Sony Eric. D750i
Sony Eric. J300i
Sony Eric. K300i
Sony Eric. K310i
Sony Eric. K320i
Sony Eric. K500i
Sony Eric. K510i
Sony Eric. K510i
Sony Eric. K530i
Sony Eric. K550i/c
Sony Eric. K550im
Sony Eric. K600i-bluerfat
Sony Eric. K600i
Sony Eric. K608i-blueat
Sony Eric. K608i
Sony Eric. K610i
Sony Eric. K610i-blueat
Sony Eric. K618i/V630i-blueat
Sony Eric. K618i/V630i
Sony Eric. K700c
Sony Eric. K700i
Sony Eric. K700i-blueat
Sony Eric. K750i-blueat
Sony Eric. K750i
Sony Eric. K790a
Sony Eric. K800i
Sony Eric. K800i-blueat
Sony Eric. K810i
Sony Eric. K810i-blueat
Sony Eric. K850i
Sony Eric. P800
Sony Eric. R320s
Sony Eric. R520

Sony Eric. S500i/c
Sony Eric. S700i
Sony Eric. T230
Sony Eric. T610-blueat
Sony Eric. T610
Sony Eric. T630-blueat
Sony Eric. T630
Sony Eric. T68i
Sony Eric. V600i
Sony Eric. V640i
Sony Eric. V800
Sony Eric. V802SE
Sony Eric. W200i/c
Sony Eric. W300i-blueat
Sony Eric. W300i/c
Sony Eric. W550i-blueat
Sony Eric. W550i
Sony Eric. w580i
Sony Eric. W610i/c
Sony Eric. W660i-blueat
Sony Eric. W660i
Sony Eric. W700i
Sony Eric. W710i
Sony Eric. W800i/c
Sony Eric. W800i/c-blueat
Sony Eric. W810c
Sony Eric. W810i
Sony Eric. W810i/W810c
Sony Eric. W830i/W830c
Sony Eric. W850i-blueat
Sony Eric. W880i
Sony Eric. W900i
Sony Eric. W910i
Sony Eric. W950i
Sony Eric. Z1010
Sony Eric. Z310i
Sony Eric. Z310i/Z310c
Sony Eric. Z520i
Sony Eric. Z530i/Z530c
Sony Eric. Z550i
Sony Eric. Z558i
Sony Eric. Z600
Sony Eric. Z610i
Sony Eric. Z800

TELTONIKA

Teltonika TM2 GSM/GPRS
USB modem

TOSHIBA

Toshiba TS 608